



READ THIS DOCUMENT CAREFULLY BEFORE PROCEEDING

GM DCBS EL-52800 Packaging Contents

MAIN BOX

- Trolley
- User Manual
- Quick Guide

DOCKING STATION BOX

- Docking Station with Handle
- Remote
- Thermal Printer

POWER CABLE BOX

- Trolley Clamps (16.4' - 5m)
- Power Cord (16.4' - 5m)

ACCESSORIES BOX

- Remote Clamps (4.9' - 1.5m)
- 2 - M6 - 35mm Screws and Nut Fasteners (4mm Allen Wrench and 10mm Socket Wrench Required)
- 8 - M5 - 10mm Screws (3mm Allen Wrench Required)
- Printer Paper Roll
- 2 - Trolley Cable Hooks
- 1 Ethernet Cable

CONTACT US

TECH SUPPORT - USA
1-877-453-3265 *English*
support.usa@e-xteq.com

HOURS OF OPERATION (EST)
Monday - Friday: 8 am - 8 pm

Comprehensive support also available through www.e-xteq.com

- 1** Open the box carefully by using a Box Cutting Knife or similar tool and remove the protective foam like the picture shown below.



- 2** Gently pull up the "Docking Station" box and turn the box over to prevent damaging the ends of the handle.



- 3** Remove the "Accessories" box and set aside for later instructions.



- 4** Gently lift the box vertically. Note: For your safety, ask for help when lifting this product.



- 5** Remove the "Power Cables" box and set it aside for later use.



- 6** Pull/Roll the Trolley out of the box. NOTE: Have one person to hold the box while the other pulls/rolls the trolley out of the package.



DCBS ASSEMBLY PROCEDURE

- 1** Open the "Docking Station" box and remove the docking station by pulling the handle up.



- 2** Remove the remote from the docking station and set it aside.



- 3** Connect the cables between docking station and trolley. Make sure the cables are properly connected. Push the cable all the way inside the trolley tube as shown in the picture below.



- 4** Once the cable connector is inside the tube, attach the handle to the trolley and secure it with the two 6M-35mm screws and nuts.

NOTE: Screw can damage cable connector. Use caution when inserting screw on connector side.



- 5** After attaching the docking station tighten the screws on the handle.



- 6** Mount the trolley and remote cable hooks with the 5M - 10mm screws.



- 7** Insert paper roll in the printer as shown below.



- 8** Open the "Power Cable" box and connect the charging clamps and the power cord to the trolley.

