E-XTEQ

BC1012 ECU REFLASH QUICKGUIDE

1 MAIN MENU

The Main Menu has three icons. Charge, History and Settings. Select the Charge Icon to Proceed.

Main Menu

12.95V

2 SELECT CHARGING MODE

Select ECU Reflash Mode.

Select Charging Mode

12.95V

3 WARNING

Warning screen displays before test starts.

Warning

CAUTION

Warning : 1500W High Power

Power output will be activated to initialize the power supply

For your safety, please ensure clamps connection before continuing

4 PRESS TO START

Click "✓" to to start test.

Press to Start

5 POWER SUPPLY

Power supply mode in charge.
To stop the charge, press the stop button.

Power Supply

00:06   13.37 V

%   10.23 A
15.00 A

STOP

6 STOP CHARGING

Click "✓" to confirm the stop,
Click "X" to go back to charging.

Stop Charge?

7 MAIN MENU

After stopping charge, it will go back to the Main Menu.

Main Menu

12.95V

CONTACT US

TECH SUPPORT - USA
1-877-453-3265 English
support.usa@e-xteq.com

HOURS OF OPERATION (EST)
Monday - Friday: 8 am - 8 pm

Comprehensive support also available
through www.e-xteq.com